


Parts & Hardware

A		x 1 PC
B		x 1 PC
C		x 1 PC
D		x 1 PC
E		x 1 PC
F		x 1 PC
G		x 1 PC
H		x 2 PC
I		x 1 PC
J		x 1 PC
K		x 1 PC

Garden Trading®

Frilford Egg Chair Assembly Instructions

Please read through these instructions and ensure they are kept for future reference.
All parts and hardware are listed on the back of this guide.



Care Instructions

These instructions include important information about the assembly, use and care of your furniture.
Please take a moment to read through the instructions before beginning the step by step process.

Assembly Advice




Ensure that two people assemble the product together. Parts can be heavy.
Power tools are not required to assemble this product. Everything you need for the build is included with the furniture.
Check that you have all the parts listed before you discard any packaging.
Assemble the furniture on a non-abrasive surface such as a dust sheet or the original cardboard packaging.
Do not over-tighten screws.
Please ensure product is fully assembled before use.
Keep small parts out of reach of children.
Make sure all legs are fitted securely and are in contact with the ground.

Garden Trading®

gardentrading.co.uk

customerservices@gardentrading.co.uk

TGTC, Hargreaves Road, Groundwell Industrial Estate, Swindon, SN25 5AZ



Care & Maintenance:

To maintain the condition of your furniture, we recommend that you follow the guidance below:

Furniture cushions

- During prolonged periods of non-use or inclement weather, store furniture cushions away in a dry and well-ventilated indoor space. Make sure all cushions are clean and dry when putting them away.
- Complete regular visual check to inspect for mould, mildew or animal damage.
- Remove spillages immediately with an absorbent sponge or cloth.

Rattan & synthetic rope

- Use a soft brush to clear away and leaves or garden debris. If there are any dirty marks on the rattan, clean with a non-abrasive sponge and lukewarm, detergent-free soapy water. Rinse with fresh water and allow to dry.
- We recommend the use of a furniture cover when your furniture is not in use

Aluminium

- Clean the frame with a non-abrasive sponge and warm soapy water, rinse with fresh clean water. The aluminium is powder-coated and can be left outside all year with minimal maintenance required.
- We recommend the use of a furniture cover when your furniture is not in use to protect it from garden debris and bird excrement.

